

INFINITY 1500 PORTABLE POWER STATION USER GUIDE



CONTACT US
www.growatttable.com

CATALOGUE

Important Safety Instructions	1
Package Contents	2
Getting to Know the Infinity 1500	3
LED Display	3
How to Use	5
How to Recharge	5
Instructions for Advanced Features	10
How to connect to APP	12
Technical Specification	16
FAQ	17
Error Codes	18
Troubleshooting	19

Important Safety Instructions

Warning – Please read the instructions carefully before you use the product.
You must follow the precautions below when using this product.

- Usage**
- Read all the instructions before using the product.
 - Do not put fingers or hands into the product.
 - Do not stack any heavy objects on the product.
 - To reduce risk of damage to the electric plug and cord, pull the plug rather than the cord when disconnecting the power pack.
 - Please avoid impact, falls or severe vibrations when using the product. Do not use the product after it has been by a strong force or dropped from a height.
 - Do not use wires or other metal objects to cause product short circuit.
 - If you accidentally drop the product into water while using it, please stay away from the product and keep it in a safe open area until the product is completely dry. The dried product should not be reused again and should be disposed of properly according to the disposal guide in this manual.
 - Do not use the product in an environment of strong static electricity or magnetic field; otherwise, it may cause the product to malfunction or even serious damage.
 - Do not use a battery pack or appliance that is damaged or modified. Damaged or modified batteries may exhibit unpredictable dangers resulting in fire, explosion or risk of injury.
 - If the product catches fire, it is recommended to use fire extinguishing equipment according to the following priorities: water or mist, sand, fire blanket, dry powder, carbon dioxide fire extinguisher.
 - You may use a dry cloth to clean the dirt on the product.

1


Storage and Transportation

- Keep the product out of the reach of children and pets. If your child accidentally swallows product parts, seek for medical help right away.
- For long-term storage, keep the battery level between 30%-80% and store it indoors. If the battery of the product is in a low-power state for a long time, the battery will enter a deep sleep mode, and the battery may even be damaged in a serious low-power state. To wake the battery from deep sleep, please recharge the portable power station.
- Do not place the product near a heat source, such as a fire or a heating furnace. The product should be stored in a dry environment. Do not place the machine in water or when it is soaking.
- During transportation, please make sure that the power of the product is less than 30%.
- Do not store or transport this product with eyeglasses, watches, metal necklaces, hairpins, or other metal objects.


Disposal Guide

- Be sure to completely discharge the machine battery before placing the machine battery in the designated battery recycling bin. Batteries are hazardous chemicals and should not be disposed of in ordinary trash cans. Follow local laws and regulations for battery recycling and disposal.
- Please dispose of over-discharged batteries that cannot be recharged.


Package Contents




Infinity 1500 Portable Power Station



User Manual and Warranty Card



1.5m AC Charging Cable




MC4 to XT60 Solar Panel Charging Cable




1.5m Car Charging Cable

2

Getting to Know the Infinity 1500



LED Display



3

Indicators

Indicators	Description
a	Remaining Charge Time: The remaining charging time calculated by the system based on the current power consumption, accurate to 1 hour.
b	Input Power: The total input power of wall chargers, solar chargers, and car charging.
c	AC Input Indicator: AC Input power is being charged using the wall charger.
d	PV Input Indicator: Infinity 1500 is being charged using the solar panels.
e	Car Input Indicator: Infinity 1500 is being charged using the car charger.
f	Remaining Battery Percentage: Displays the current remaining battery percentage in real time.
g	Car Output Indicator: Infinity 1500 is supplying power to external devices via the car output port.
i	USB-A Output Indicator: Infinity 1500 is supplying power to external devices via USB-A ports.
j	USB-C Output Indicator: Infinity 1500 is supplying power to external devices via USB-C ports.
k	Output Power: The total output power of DC, AC, and wireless charging.
l	Output Voltage and Frequency: Displays the current AC output voltage and frequency.
m	Remaining Discharge Time: The remaining discharging time calculated by the system based on the current power consumption, accurate to 1 hour.
n	OVERLOAD Warning: The current total output power is higher than 2000W, the AC output will be stopped for safety protection.
o	System Alert: The product is not working properly. Check the error codes in the appendix to understand the cause of the error and fix the problem.
p	High Temperature Warning: The temperature of Infinity 1500 is too high. Please place the product in an open area for cooling.
q	Low Temperature Warning: The current battery temperature is low, and the charging efficiency will be reduced. Keep using the product, and the charging efficiency will return to normal as the temperature rises.
r	Bluetooth Warning: The product is connected to Bluetooth and can be controlled remotely through the MyGoAPP.
s	Fan Status Indicator: The fans running to cool the product.
t	UPS Indicator: The product has turned on UPS mode to provide uninterrupted power to your devices.
u	Wi-Fi Indicator: The product is connected to Wi-Fi and can be controlled remotely through the MyGoAPP.

4

How to Use

Before use, please put Infinity 1500 on a clean and flat ground to ensure that the machine will not be in contact with liquid or tilted, and check whether there are foreign objects on the body.

Product ON/OFF

- 1) Turn on the Infinity 1500, long press the power button until the screen lights up.
- 2) To turn off the Infinity 1500, press and hold the power button until you hear a beep and observe the "OFF" prompts on the screen.

LCD Screen

- 1) Short press the DC power button to turn on the DC output supply (including all USB ports and car output port). You should hear a "beep" sound and observe that the DC power indicator lights up.
- 2) Short press the DC output power, short press the DC power button. You should observe that the DC power indicator lights off. When the output power of a single DC port exceeds the rated power below, the system will trigger an overload alarm and cut off the DC output.

The maximum output power of a USB-A port is 12W.
The maximum output power of a Fast Charge USB-A port is 18W.
The maximum output power of a USB-C port is 60W.

AC Power ON/OFF

- 1) To turn on the AC output supply, short press the AC power button, and you will observe the AC power indicator lights on. Wait for 3 seconds to activate the AC power supply, then you should be able to charge your equipment using AC output ports.
- 2) Long press the AC power button for 6 seconds to change AC frequency mode (50HZ/60HZ).

The total output power of the AC output ports is up to 2000W (the sum of the four ports). When the total output power exceeds the rated power, the product will trigger overload protection, cut off the AC output and prompt an overload alarm. Unplugging the AC load will clear the alarm and restore normal AC output.

Wireless Charging

Wireless charging is activated when the DC power is turned on. You can charge wirelessly by placing the device within the wireless charging range on the top of the product.

This feature is only available for devices that support wireless charging. You can check the wireless charging status by looking at the LED indicators on the wireless charging panel.

Slow breathing blue: your device is being charged wirelessly.
Flash blue: an error occurred during wireless charging.
Steady green: wireless charging is ready, but no devices are detected.

5

How to Recharge


Notice before charging.

- This product supports wall charging, solar panel charging, and car charging.
- Do not use a charging cable not officially designated by Growatt for charging. Otherwise, Growatt will not be responsible for any consequences.
- When charging, please make sure to place the machine away from liquids, flammable, and combustibles.
- If the product is charged immediately after full-load discharge, over-temperature protection may be triggered for battery safety reasons. It typically takes 2-3 hours for the product to cool down before another charging.
- The product's rechargeable temperature is 32F (0°C-40°C). Charging within the ideal charging ambient temperature 50F-82F (10°C-28°C) can greatly extend the battery life.

AC Charging and Car Charging


The charging ports for the Infinity 1500 locate on the left side of the product. The charging port for the Infinity 1500 is on the left side of the product. Please follow the instructions below to connect and recharge the product.

a) AC Charging



6

b) Car Charging




7

a) Connect with Growatt Solar Panels

You can charge the Infinity 1500 by connecting up to four 24V solar panels in series or using eight 12V solar panels (two sets in parallel with each set of 4 panels in series). Connect the MC4 connector on the solar panel to the MC4-XT60 adapter cable, and supply power to the Infinity 1500 through the XT60 port on the side of the Infinity. When you need to connect two solar panels, it is recommended to connect the two solar panels in parallel, and then use the MC4-XT60 adapter cable to connect the Infinity 1500 for charging.

Connecting to four 24V200W solar panels in series



8

ii) PV Charging

The series and parallel connection methods of solar panels will be explained here to ensure that you are connecting the solar panels correctly for charging. If the product is damaged due to incorrect connection not in accordance with the instructions, Growatt will not be responsible for the free maintenance of the machine within the warranty period.

The solar charging ports for the Infinity 1500 locate on the left side of the product.

The Infinity 1500 DC input range is 12V-100V. You must ensure that the input voltage is within the specified range. When the input voltage exceeds 100V, the excessive voltage may cause damage to the product, and the Infinity 1500 will trigger an overvoltage protection.

- This product supports AC and solar panel charging at the same time. The solar charging method is preferred, and the AC charging method is used to supplement when the PV input power is insufficient.

9

Connecting to eight 24V100W solar panels (two sets in parallel with each set of 4 panels in series)



10

Instructions for Advanced Features

i) UPS (Uninterruptible Power Supply)

The Infinity 1500 supports UPS (Uninterruptible Power Supply) function. In UPS mode, the AC power comes from the grid, not the battery. When the power grid is cut off, Infinity 1500 will automatically switch to battery power supply mode within 20ms, providing high stability power supply for your load.

a) UPS Use Guide

When using wall charging as the input method, turning on the AC output and plugging in devices on AC ports will automatically activate the UPS mode. Please connect the device according to the figure below to enable the UPS function.



11


b) Precautions before using the UPS feature

- This function is a non-professional UPS function and does not support multi-phase. Please do not connect it to equipment that is highly sensitive to unintermittent power supply, or form multiple tests before use.
- UPS only supports the use of electrical appliances below 2200W, and do not use other devices at the same time during use to avoid OVERLOAD protection.
- UPS function is only supported when one Infinity 1500 is running independently, and it is not available when multiple Infinity 1500s work in series.
- Growatt is not responsible for equipment failure or loss of data if the instructions are not followed.

ii) Multi-Unit Expansion in Series

You can use AC adapters to connect up to three Infinity 1500s in series to get a larger battery capacity. When you use this expansion method, you will need to define one of the units as the master and the rest as slaves. You need to connect the AC output port of the master unit to the AC input port of Slave 1, then connect the AC output port of Slave 1 to the AC input port of Slave 2, then plug the load device into the AC output port of Slave 2 as shown in the figure below, and finally turn on the AC output power of all Infinity 1500 to enable battery expansion.

When using this expansion method, make sure that each unit is fully charged, otherwise an overload protection will be triggered. After use, it is recommended to charge each unit separately to avoid excessive drain on the home grid.




12

How to connect to APP

i) Binding the Product with Your Device

When the product is connected to the APP for the first time, you need to use Bluetooth pairing for network configuration. Please get as close as possible to the product and make sure the phone is within the Bluetooth coverage of the device.

1. Download "MyGo" APP from App Store or Google Play. Or you may download it from the official website <http://www.growatttable.com>. For first-time users, you need to follow the instruction and complete account registration on the APP.
2. You may choose either of the following ways to connect your portable power station:
 - a) Go to the Device page and click **Add Device**. Select the "+" button at the top right of the page, then select **Add Device**.
 - b) Short press the **WiFi Rear** button to send Bluetooth & WiFi signals and connect with your mobile devices.
 - c) Follow the instruction on the APP and finish the rest of settings.




13

Local Bluetooth Control

- a) Go to the Device page and click **Pair via Bluetooth**. Or select the "+" button at the top right of the page, then select **Fast Pair**.
2. Select **Show Device**, and then select the account ID in the device to be shared, and send a binding invitation.
3. After the invited account accepts the invitation, the device is shared successfully.

- UPS function is only supported when one Infinity 1500 is running independently, and it is not available when multiple Infinity 1500s work in series.
- Growatt is not responsible for equipment failure or loss of data if the instructions are not followed.



14

ii) Re-binding the product with New Mobile Devices.

If the device is already bound to a mobile device, you need to unbind the product from the current device before re-binding it to the new mobile device. After re-binding, you can use the new mobile device to remotely control the product.

1. Unbind from the existing device.
 - a) Go to the Device page and click **Remove Device**. Select the "+" button at the top right of the page, then select **Remove Device**.
 - b) Short press the **WiFi Rear** button to send Bluetooth & WiFi signals and connect with your mobile devices.
 - c) Follow the instruction on the APP and finish the rest of settings.



15

iii) Use multiple mobile devices to control the product


If multiple users need to remotely control the product, the master account needs to authorize other myGo accounts to allow other mobile devices to control the product.

1. Go to **Device**, select the product from the device list to enter the product details, and then click the **+** to enter the setting page.
2. Select **Show Device**, and then select the account ID in the device to be shared, and send a binding invitation.
3. After the invited account accepts the invitation, the device is shared successfully.

* If the master account unbinds the device, the associated shared account will be unbound simultaneously, and the device cannot be controlled remotely.

iv) Modifying your device power output

The default power output is set to be 1800W, and it's allowed to be modified to a maximum of 2000W in the app as illustrated below. Maximizing your power output will cause extra heat which requires a faster fan speed for better cooling.



16

How to Use

Model	Infinity 1500
Capacity	1512Wh (30Ah)
Dimensions	16.9" (11.3" x 11.3" x 7.2") (237*237mm)
Weight	36.53 lbs (16.56kg)

Input Ports

AC Input	100-120V~60Hz, 1500W MAX
DC Input	12V/24V 12A MAX

Output Ports

AC Output (X4)	100V~120V/60Hz, Pure Sine Wave, Default: 1800W, 3000W surge peak, Max: 2000W, 4000W surge peak
Car Charger(X1)	13.0V/13A/130W MAX
USB-A(X2)	5V/2.4A, 12W MAX
USB-A Fast Charge(X2)	5V/2.4A, 18W/24W/30W MAX
Type-C(X2)	5V/3V, 12V, 15V, 20V/3A/60W MAX
Wireless Charging	5V, 3.1V/1.5V

Battery Information

Battery Type	Lithium-ion
Lifespan	>1000cycles to 80%
Charging Temperature	0-45°C (32-113°F)
Discharging Temperature	-20-40°C (-4-104°F)

17

FAQ

Can I take Infinity 1500 on a plane?
No, you can't. This product is a lithium battery product. According to international air transport regulations, lithium battery products exceeding 100Wh cannot be carried on the plane.

Why does the Infinity 1500 not work properly when the total output power of the device is within the rated power of the Infinity 1500?
First, please check whether the power of the product is too low, and charge the product in time. Secondly, check the instantaneous power of the equipment exceeds the instantaneous peak power of Infinity 1500. If so, you should use Growatt higher power products.

Why does the Infinity 1500 make noise when it is on?
The product adopts an air cooling system, and the built-in fan helps the product to dissipate heat. A slight noise when the product is in use is normal.

Will Infinity 1500 automatically shut down?
The Infinity 1500 will automatically shut down after 5 minutes of inactivity, and will automatically shut down after another 2 hours of inactivity. You can change the automatic screen-off and automatic shutdown times via MyGo APP.

How to clean Infinity 1500?
If the Infinity 1500 needs to be cleaned, please wipe it with a dry, non-abrasive cloth or use a special cleaner for LCD screens to achieve better cleaning results. Do not let water enter the inside of the product, which may cause damage to the circuit or panel!

18

Error Codes

Indicators	Problem	Description
A01	System Alert	Restart the portable power supply. If the problem persists after several attempts, please contact Growatt Customer Service for repair.
A02	Fan Blocked	Please check the fan is not blocked. If there is a blockage, please turn off the machine and remove the blockage. Then restart the product to return to normal. If the problem persists, please contact Growatt Customer Service for repair.
A03	High Temperature Warning	Turn off the product and place it in an open area for 2-3 hours. After cooling, the product will continue to work normally.
A04	Low Battery Voltage	The AC output is overloaded. Using the load on the output ports and keeping the total AC output power within 2000W can ensure normal operation. Overheating for a long time may cause the product to work normally.
A05	PV Input Over Voltage	The battery voltage is too low. Please recharge the battery in time.
A06	USB Output Overload	PV input voltage is too high. Please check the status of the solar panel. If the output voltage of the solar panel is normal, please contact Growatt Customer Service for repair.
A07	Product Overload	Please check the output power of your USB devices. Remove your USB devices if the output exceeds the maximum output of the USB ports.
A08	PV Input over Temperature	The Infinity 1500 is overloaded. Unplug part or all of the loads and keep the total output within 2000W to ensure normal operation.
A09	Discharge Over Temperature	Disconnect the solar panels from the portable power station to ensure normal operation.
A10	High Temperature	Turn off the product and place it in an open area for 2-3 hours. After cooling, the product will continue to work normally.
A11	Low Battery Temperature	Keep discharging the power station, the temperature will rise and the product will resume normal status. If the error persists, contact Growatt Customer Service for repair.
F02	Car charging overcurrent	Please check whether the input meets the specification of car charging. Remove the car charger to resume normal operation.
F01	System Failure	Restart the portable power supply. If the problem persists after several attempts, please contact Growatt Customer Service for repair.
F02	Output Short Circuit	Restart the portable power supply. If the problem persists after several attempts, please contact Growatt Customer Service for repair.
F03	Product Over Temperature	Turn off the product and place it in an open area for 2-3 hours. After cooling, the product will continue to work normally.
F03	Input Overload	Please make sure the total output power is within the acceptable range. Remove the excess loads to resume normal operation. If the problem persists, contact Growatt Customer Service for repair.

19

Troubleshooting

Indicators	Troubleshooting	Description
	1. Check if the charging cable is not plugged in properly.	Double check the the reverse of the charging cable (in a good contact).
Unable to start up the Infinity 1500	2. Please check whether the Overload Protection button (next to the input ports) is in the pop-up state.	Press the overload protection button.
	3. Didn't fix any of the problems above.	Contact Growatt Customer Service for repair.

Indicators	Troubleshooting	Description
Infinity 1500 power off device	1. Check if the battery is not plugged in properly.	Please make sure the battery is in good connection with the input ports.
	2. Please check the AC/DC power indicator and see if the output power is turned on.	Press the AC/DC power button to turn on AC/DC output supply. You should see the AC/DC indicator light up once the output power is turned on.
	3. Please check if the battery is too low.	Please recharge the INFINITY 1500 in time.
	4. Please check if the battery temperature exceeds the usage range of Infinity 1500.	Please choose a model with a higher rated power.
	5. Didn't fix any of the problems above.	Contact Growatt Customer Service for repair.